



Graphene Coating Installation Instructions + Tips

OAS Graphene Coating Installation

*Proper installation is VITAL to get the most out of your OAS Graphene Coating.
Improper installation may severely reduce life of the graphene coating.*



The Prep

- +Wash the vehicle, preferably with a wax stripping shampoo.
- +Clay the entire vehicle thoroughly with a moderate to aggressive clay bar, towel, or mitt.
- +(Recommended) Perform paint correction on the vehicle to remove or lessen imperfections.
- +Remove all wax, polish, etc., with IPA solution/degreaser.



The Install

- +Wear gloves and a mask if in an unventilated area.
- +Do not install in direct sunlight.
- +Apply 5-7 drops onto the applicator
- +Work in 1'x1' areas in an overlapping crosshatch pattern.
- +After applied, wait 15 seconds and wipe using MF towels.
- +Two towel method is best, one for the initial wipe and another for buffing after.



Curing + After-Care

- +Wait time between layering is 2 hours.
- +2 Layers recommended, more than 3 not recommended.
- +Avoid water for 12 hours after the final layer.
- +Avoid washing, chemicals, bird droppings, etc, for 6 days.
- +Avoid drive-through carwashes entirely
- +Wash with PH neutral or ceramic infused shampoos.
- +Wash bi-weekly for best maintenance.



Final Tips

- +Highspots can be removed within 1 hour simply by applying more graphene coating to the area and buffing off.
- +When wiping and buffing off the product, if towels become saturated and ineffective, use new towels.
- +If in warmer or more humid weather, wipe/buff immediately after application.
- +Don't skimp on the product when applying to the applicator.

*If you have any questions or concerns, reach out to us! 915-549-3728 or obsidianautospa@gmail.com
Thank you for trusting Obsidian Auto Spa with your vehicle!*